

WERNERVOß

Kronleuchter Versailles

Artikel Nr.: 33318

Packungsinhalt

- Kronleuchter Versailles
- Bedienungsanleitung

Technische Daten

- 15 flammig
- Fassung: E14 (GLÜHBIRNE NICHT ENTHALTEN)
- max. 40 W
- Maße: 64x68 cm

Anwendungs- und Warnhinweise

(Lesen Sie die Bedienungsanleitung vor Inbetriebnahme des Gerätes aufmerksam durch, um sich mit den Funktionen des Gerätes vertraut zu machen. Bewahren Sie die Anleitung zum späteren Nachlesen oder bei Weitergabe sorgfältig auf)

- Der Artikel ist ausschließlich zur dekorativen Beleuchtung geeignet.
- Der Artikel ist für den Innenbereich geeignet.
- Den Artikel vor dauerhafter Feuchtigkeit schützen!
- Der Artikel darf nicht in der Verpackung betrieben werden! Vorsicht Brandgefahr!
- Ist eine Beschädigung am Kabel oder Stecker vorhanden, sollten Sie von dem Gebrauch des Artikels absehen.
- Der Artikel darf nicht mit anderen Lichterketten o.ä. elektrisch verbunden werden.
- Von Hitze, Funken und Feuer fernhalten!
- Dekorationsartikel, KEIN SPIELZEUG!!!
- Den Artikel von Kindern fernhalten!
- Die Inbetriebnahme und Bedienung des Artikels sollte ausschließlich von Erwachsenen vorgenommen werden.

Montageanleitung

- Entnehmen Sie den Artikel aus der Verpackung.
- Montieren Sie die Teile entsprechend der Aufbauanleitung.
- Setzen Sie ein passendes Leuchtmittel in die Fassungen.

Reinigung

- Den Artikel immer vor jeder Reinigung ausschalten! Reinigen Sie den Artikel nur mit einem trockenen Tuch oder Staubwedel.

Entsorgung von elektronischen Geräten



Elektronische Geräte gehören nicht in den Hausmüll! Entsorgen Sie elektronische Geräte über die öffentlichen Rücknahmestellen. Weitere Informationen erhalten Sie bei Ihrer Gemeinde oder den zuständigen kommunalen Entsorgungsbetrieben.

Werner Voß GmbH • Feldstiege 60 • D-48161 Münster



WERNERVOß

Chandelier Versailles

Item no.: 33318

Package contents

- Chandelier Versailles
- Instruction manual

Technical data

- Socket: E14 (LIGHT BULB NOT INCLUDED!)
- max. 40 W
- Dimension: 64x68 cm

Instruction for use and warnings

(Read the operating instructions carefully before operating the device in order to familiarize yourself with the functions of the device. Keep the instructions in a safe place for future reference or when passing on)

- The item is suitable for decorative lighting only.
- The article is suitable for indoor use.
- Protect the article from permanent moisture!
- The article must not be operated in its packaging! Caution: Fire hazard!
- If there is damage to the cable or plug, you should refrain from using the item.
- The article must not be electrically connected with other fairy lights or the like.
- Keep away from heat, sparks and fire!
- Decorative item, NOT A TOY!!!
- Keep the item away from children!
- The commissioning and operation of the article should only be carried out by adults.

Assembly instruction

- Remove the item from the packaging.
- Assemble the parts according to the assembly instructions.
- Insert a suitable light source into the socket.

Cleaning

- Always switch off the article before any cleaning! Only clean the article with a dry cloth or feather duster.

Disposal of electronic devices



Electronic devices do not belong in household waste! Dispose of electronic devices via the public collection points. For more information, contact your local authority or the relevant municipal waste disposal companies.

Werner Voß GmbH • Feldstiege 60 • D-48161 Münster

