

ASSEMBLY INSTRUCTIONS OF MINERAL MARBLE WASHBASIN



Lavabo carga mineral Mineral marble washbasin

SOLID	cod.
60	82568
80	82569
100	82570
120	82571
120 2S	82572



Firstly, set the drill points, according to the scheme and dimensions of the drawing for a installation at the recommended height. Then, drill a hole at each point and insert the appropriate screw and plug for each

Hang the washbasin over the screws by passing these scrfews through the holes that the washbasin has on the rear fase.

Finally, to ensure the washbasin, thread the Nylon caps on each of the screws.