



# USER MANUAL

## „ARIZONA“ FIREPLACE





**1. Introduction**

Thank you for choosing the Arizona Garden Fireplace. This user manual provides essential information regarding proper usage, maintenance, and safety precautions to ensure you enjoy the warmth and ambiance of your fireplace for many years.


The Arizona fireplace is an elegantly designed outdoor feature made from high-quality steel, finished with a durable painted coating. This protective layer ensures greater resistance to weather elements compared to unpainted models. However, to maintain its longevity and aesthetic appeal, regular care is still recommended.

**2. Product Specification:**

The Arizona Garden Fireplace is built for outdoor spaces and is available in one size. The painted finish adds both durability and a sleek look to complement your garden or patio.

**Specification:**

SYMBOL	LENGTH/D EPTH	HEIGHT	WEIGHT
P-KOM-ARIZO-LA000	39,5x55cm	117cm	17 kg



**3. Material information**

The Arizona fireplace is made from sturdy, painted steel, designed to withstand outdoor conditions. The painted finish serves to protect the steel from rust, moisture, and other environmental factors, but still requires periodic upkeep to ensure its longevity.

- **Painted Steel:** The paint provides a barrier between the raw steel and the elements. Unlike unpainted models, this fireplace is more resistant to rust. However, exposure to harsh weather can cause the paint to chip or wear down over time, which will expose the steel underneath.

**Why Maintenance is Important:**

Even though the Arizona fireplace comes with a protective paint layer, it's important to inspect the surface regularly for signs of wear, rust spots, or paint damage. Proper maintenance will help preserve both the functionality and appearance of the fireplace.



#### 4. Regular maintenance

Proper maintenance is key to ensuring that your Arizona Outdoor Fireplace stays in excellent condition.

##### After Each Use:

- **Clean the Fireplace:** After the fire has cooled, remove all ash and debris from the interior of the fireplace. A clean surface helps prevent damage to the painted steel.
- **Inspect for Damage:** Check the painted surface for any cracks, chips, or peeling. If you notice any areas where the steel is exposed, touch them up with heat-resistant paint to prevent rusting.

##### Monthly Maintenance:

- **Apply Protective Coating:** While the fireplace is painted, additional protection can be gained by applying a heat-resistant sealant or paint to the surface at least once a season (or as needed based on usage and weather exposure).

##### Long-Term Storage:

- **Cover or Store Indoors:** When not in use, especially during the off-season or in rainy weather, store the fireplace in a dry place or use a waterproof cover to protect it from the elements.
- 

#### 5. Installation instructions

To ensure safe use and prolonged durability, follow these installation steps:

##### Choosing the Right Location:

1. **Stable and Level Ground:** Place the fireplace on a stable, non-combustible surface like brick, stone, or concrete. Avoid placing it directly on wooden decks or flammable surfaces.
2. **Safe Distance:** Keep the fireplace at least 2 meters away from any structures, trees, plants, or other flammable objects.

##### Assembly:

1. **Attach the Chimney:** The Arizona fireplace comes in two main parts: the body and the chimney. Assemble these according to the instruction manual, ensuring the chimney is securely fastened.
  2. **Positioning:** Once assembled, place the fireplace in your desired location. Ensure it is positioned in a spot with good airflow to allow the smoke to escape safely through the chimney.
-



## 6. Operating instructions

Once the fireplace is set up, it's ready for use.

### Lighting a Fire:

1. **Arrange Firewood:** Start by placing small, dry kindling at the bottom of the fireplace. Stack larger pieces of wood on top, ensuring there is enough airflow between the logs.
2. **Ignite the Fire:** Light the kindling using matches or a lighter. Allow the small wood to catch fire before adding larger logs.
  - o **Note:** Do not use lighter fluid, gasoline, or other accelerants. These can cause dangerous flare-ups and damage the painted surface.

### Managing the Fire:

- Keep the fire moderate, avoiding overly large flames that could overheat the fireplace or cause paint to blister. Always monitor the fire while it is burning to ensure safety.

### Extinguishing the Fire:

- Allow the fire to burn out naturally. Never douse the fire with water, as sudden temperature changes can cause thermal shock and damage the fireplace. Wait until the fireplace is completely cool before cleaning or moving it.

---

## 7. Safety precautions

To ensure safe and enjoyable use of your ARIZONA fireplace, always adhere to the following safety precautions:

1. **Never leave unattended:** always have an adult present when a fire is burning. Do not leave the fireplace unattended, especially when there are children or pets nearby.
2. **Keep Children and Pets at a Safe Distance:** Always ensure that children and pets remain at a safe distance from the fireplace. The high temperatures and open flames pose a significant risk of burns or accidents.
3. **Avoid Flammable Materials:** Do not place the fireplace near flammable objects such as tents, outdoor furniture, wooden decks, or overhanging tree branches. Maintain at least a 2-meter clearance from any combustible materials.
4. **Use Heat-Resistant Gloves:** When handling or adjusting the fireplace during use or after the fire has gone out, always wear heat-resistant gloves. The steel can remain hot for several hours after the fire has extinguished.
5. **Have Emergency Equipment Ready:** Keep a fire extinguisher, bucket of water, or garden hose nearby in case of emergencies. This will allow you to quickly extinguish any uncontrolled flames or embers.



### 8. Storing the fireplace

To maximize the lifespan of your Arizona Garden Fireplace, proper storage is essential:

1. **Clean Before Storage:** Once the fireplace has cooled, remove any remaining ash or debris. Check for damage to the painted surface and perform touch-ups if needed.
2. **Cover or Store Indoors:** Store the fireplace in a dry, sheltered place such as a garage or shed during periods of non-use. If left outdoors, cover it with a waterproof cover to protect it from rain, snow, and humidity.
3. **Inspect After Storage:** Before using the fireplace after long-term storage, inspect the painted surface to ensure there are no signs of damage or rust.

### 9. Disposal and recycling

When the time comes to dispose of your Arizona Garden Fireplace, follow these environmentally friendly steps:

1. **Recycling:** The steel components of the fireplace can be recycled at a local scrap metal facility. Contact your local recycling center for details on how to dispose of metal products.
2. **Proper Disposal:** If recycling is not available, check with local authorities for appropriate waste disposal options.

**Thank you for choosing ARIZONA fireplace! By following this manual, you will ensure that your fireplace provides safe and enjoyable use for many years to come.**

**Please check our other accessories.**

