### INSTALLATION INSTRUCTION


TWO HANDLES WASHBASIN MIXER

#### **XACCESSORIES CHECKING**

#### LIST OF THE STANDARD ACCESSORIES:

Please double-check the accessory list hereinafter and contact our company or our distributor for any unconformity. Remarks:


- 1. Without affecting their performancing, accessories may be changed without further notice;
- 2.Drawings for reference only, Product size & shape refer to actual faucet.





Code	The Accessory List	Quantity
1	Main body	1
2	0-ring	1
3	Cushing	1
4	Gasket	1
5	Fixing bolt	1
6	Nut	1
7	Inlet pipe	2


#### **XInstallation Instructions**

- ☆ Do not disassemble the main body, as it has been installed & commissioned correctly & precisely before leaving the factory;
- ☆ To avoid the faucet from jamming,do flush the water pipe before installation;
- ☆ After installation,make sure every joint safely sealed & no leaking;
- ☆ Using condition:Working pressure at 0.05-1.0MPa(including cold & hot water pressure), with applicable water temperature:4°C-90°C;
- ☆ Make sure to connect the hot/cold inlet pipe correctly,if standing in front,hot water pipe connecting to the left & cold water pipe connecting to the right.










### **%Installation Procedures**

- ☆ Make sure the installation holes to be in right size;
- ☆ Connect the main body & water supply pipe with water inlet pipe.




### **%Usage**


- ☆How to operate the handwheel
- 1. The left handwheel: To turn on the hot water directly, The largest rang is 90°, and turn off rightabout.
- 2. The right handwheel: Toturn on the cold water rightabout and turn off directly.

# 

- ☆ To keep the product clean & shining, follow the as below:
  - 1. Flush with clean water & dry with soft cloth only;
  - 2.If any dirt, clean with soft liquid or transparent glass detergent;
  - 3.Do not use any scrubbing detergent, polisher, sane-cloth, paper tissue or scraper,
  - 4.Do not use acid detergent indissovable grain-like detergent or soap;
  - 5. Circumrotate the aerator off and clean it when necessary.








#### **%Installation Procedures**

- ☆ Make sure the installation holes to be in right size;
- ☆ Connect the main body & water supply pipe with water inlet pipe.



# **%Usage**

- $\stackrel{_{}}{
  m iny}$  How to operate the handwheel
- 1. The left handwheel: To turn on the hot water directly, The largest rang is 90°, and turn off rightabout.
- 2. The right handwheel: Toturn on the cold water rightabout and turn off directly.

## **XCleaning & Maintenance**

- ☆ To keep the product clean & shining,follow the as below:
  - 1.Flush with clean water & dry with soft cloth only;
  - 2.If any dirt, clean with soft liquid or transparent glass detergent;
  - 3.Do not use any scrubbing detergent, polisher, sane-cloth, paper tissue or scraper;
  - 4.Do not use acid detergent indissovable grain-like detergent or soap;
  - 5. Circumrotate the aerator off and clean it when necessary.

