




ASSEMBLY INSTRUCTION ST31-FX

Ax1 	Bx4 	Cx16  M8x16	Dx16  M8x18	Ex1  M5	Fx4 	
--	--	--	--	--	--	--



A	x1	B	x4			
						
C	x16	D	x16	E	x1	
 M8x16		 M8x18		 M5	F	x4
						

