

2)


IMPORTANT—Please read prior to installation


- 1) Please read these instructions carefully before commencing any work
 - Please retain these instructions for future reference
- 3) This unit must be installed by a qualified electrician in accordance with the IEE wiring regulations and building regulations
- 4) To prevent electrocution switch the power off at the mains supply before installing or maintaining this fitting
- 5) Ensure others cannot restore the electrical supply without your knowledge







INSTALLATION INSTRUCTIONS






INSTALLATION INSTRUCTIONS (CONT)







Switching on/off

Press the touch button in front of the mirror, and the mirror will turn on the touch switch again. Long press the touch switch to adjust the brightness, and double click the touch button to switch the CCT

Demister Function

The demister will automatically switch on when the sensor button is pressed to switch light on.

Demister will switch off automatically after 60 minutes.

CARE IN USE

Please note this fitting has non replaceable parts

Always switch off or disconnect from the mains when cleaning the product.

We recommend cleaning with a soft dry cloth. Do not use scourers, abrasives or chemical cleaners.

Do not allow moisture to come into contact with electrical parts

This luminaire should not be disposed of with normal household rubbish. When a replacement is purchased, this luminaire should be returned to the retailer to safely dispose of (WEEE Directive effective July 2006—Waste from Electrical & Electronic Equipment)





This product contains a light source of energy efficiency class G