

Corten steel water fountain procedure

Assembling & Using Your Product

Unpack all components carefully. Please check to ensure all parts have been removed from the packaging.

Components:

One (1) –Water pump assembly kit

One (1) –Pebbles

Two (2) –Metal trays


Specific Installation steps as follows:

IMPORTANT: 2 peoples are required to safely assemble and install this unit. Do not attempt to assemble on your own.

Step 1


Place Metal Base on a level surface at desire location, then slide the panel into the base.

And tighten the wing nuts securely till panel stands in upright position in the base.



Step 2

Connect the ball valve to the water pump, tighten and secure the hose clamp with a screwdriver. Then connect them to the PVC pipe coming out from the bottom of the panel.



Step 3


Feed pump wire through the hole on the back of the base.

Step 4

Fill in enough water to make sure the pump is completely submerged, and under the hole. Then cover the metal try with decorative pebbles on the base.

Step 5

Plug the pump into main powder supple when use.



Care & Maintenance

1, There are two adjusting screws at the bottom of the panel. If the water flow on the left side of the fountain top is weak, you can tighten the left screw; conversely, tighten the right screw.

2, Use the ball valve to adjust the water flow.

3, The water fountain will continue to lose water due to evaporation, which is dependent on many variables such as climate, humidity, temperature, etc. It is very important that the water level is maintained at all times. If the pump runs dry or water level is too low, it may cause the pump to burn out or work improperly, voiding all warranty.

Caution

Always unplug the pump from the electrical outlet before cleaning & handling.

Uses with clean water only, do not place the fountain and/or parts in any other liquid.

Periodically change water & clean the pump to keep free from micro-organisms

Disconnect and store the unit in a dry place if not in use for an extended period of time

Do not operate with water above 90°F or 30°C

NEVER LET THE PUMP RUN DRY

Corten steel vattenfontän – procedur

Montering och användning av din produkt

Packa upp alla komponenter försiktigt. Kontrollera att alla delar har tagits bort från förpackningen.

Komponenter:

En (1) – vattenpumpsenhet

En (1) – småstenar

Två (2) – metallbrickor

Specifika installationssteg enligt följande:


VIKTIGT: Det krävs 2 personer för att säkert montera och installera denna enhet.

Försök inte att montera den på egen hand.

Steg 1

Placera metallbasen på en plan yta på önskad plats, skjut sedan panelen ner i basen.

Dra åt vingmuttrarna ordentligt tills panelen står upprätt i basen.




Steg 2

Anslut kulventilen till vattenpumpen, dra åt och säkra slangenkälet med en skruvmejsel. Anslut dem sedan till PVC-röret som kommer ut från panelens undersida.

Steg 3

Mata pumpens ledning genom hålet på baksidan av basen.




Steg 4

Fyll på med tillräckligt med vatten så att pumpen är helt nedsänkt och befinner sig under hålet. Täck sedan metallbrickan med dekorativa småstenar på basen.

Steg 5

Anslut pumpen till huvudströmkällan vid användning.



Skötsel och underhåll

1. Det finns två justeringsskruvar på panelens undersida. Om vattenflödet på vänster sida av fontänens ovansida är svagt, kan du dra åt den vänstra skruven; om det är svagt på höger sida, drar du åt den högra skruven.
2. Använd kulventilen för att justera vattenflödet.
3. Vattenfontänen kommer kontinuerligt att förlora vatten på grund av avdunstning, vilket beror på många variabler som klimat, luftfuktighet, temperatur etc. Det är mycket viktigt att vattennivån upprätthålls hela tiden. Om pumpen går torr eller vattennivån är för låg, kan det leda till att pumpen bränns ut eller fungerar felaktigt, vilket ogiltigförklarar all garanti.

Försiktighet

- Dra alltid ut pumpens stickkontakt ur eluttaget före rengöring och hantering.
- Använd endast med rent vatten. Doppa inte fontänen och/eller delar i någon annan vätska.
- Byt vatten regelbundet och rengör pumpen för att hålla den fri från mikroorganismer.
- Koppla bort och förvara enheten på en torr plats om den inte används under en längre tid.
- Använd inte med vatten som är varmare än 30 °C.
- LÅT ALDRIG PUMPEN GÅ TORR.