




# ASSEMBLY INSTRUCTIONS

PEEK INTO THE COSMOS MIRROR

Thank you for your purchase!



## NOTE:

For safe mounting, it is essential to use the proper hardware for your wall type (drywall, concrete, etc.). Contact your local hardware store for assistance if necessary. For safety and ease of mounting, installation is recommended using two people.

This mirror includes two 'D' rings on the back for mounting as illustrated in the picture for hanging to a wall.

### Tools needed

Level, Tape Measure, Stud Finder, #2 Phillips screw driver, pencil

### Hardware included:

- (2) plastic anchor
- (2) metal screws (for dry wall only)
- For stud mounting the anchors are not required, use only the screws.

### Mounting Instructions:

1. Determine your desired hanging location. Measure the distance between the d-rings on the back of the mirror, making sure the measurements are taken from the centers of both d-rings.
2. Record this measurement on the wall with a pencil. Use a carpenter's level and a tape measure to ensure a level installation.
3. Stud mounting is always best, so try to position the d-rings over studs if possible. Use a stud finder to locate a stud in desired location. If any of the d-rings align with stud, use provided metal mounting screws. If there is no stud, the wall anchors/metal screws are both required.

### Dry wall mounting:

1. Use a Phillips screwdriver to insert the wall anchors. Do not 'push' or drive the anchors into the wall, it is designed to bore into the wall like a drill bit. Slowly turn the anchors clockwise while applying pressure until the flange just touches the wall.
2. Insert the metal screw into the wall anchor turning clockwise leaving approximately  $\frac{1}{2}$ ' between the back of the screw head and the wall.
3. Align the d-rings over the screw heads and slide the mirror down until the tops of the d-rings rest on the screws. Tighten or loosen screws as needed to fit the mirror snugly against the wall.

### Stud Mounting:

1. With a Phillips screw driver (or drill) insert metal screws into the stud clockwise until tight.
2. Align the d-rings over screw heads and slide the mirror down until the tops of the d-rings rest on the screws.